

Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6




Fig. 7

Close SBS Contactors
Flow Chart





Fig.8






Fig. 9




Fig. 10




Fig. 11




Fig. 12




Fig. 14




Fig. 15




Fig. 16




Fig. 17a

Rectifier Control Block Diagram




Fig. 17b




Fig. 18A




Fig. 18B




Fig. 18C





Fig. 19

Switch (0=OFF, 1=ON)			Line to Neutral Voltage Vectors					Line to Line Voltage Vectors				
S_{Ct}	S_{Bt}	S_{At}	V_{AN}	V_{BN}	V_{CN}	$V = [V_{Ct}, V_{Bt}]^T$	Vector	V_{AB}	V_{BC}	V_{CA}	$V = [V_{Ct}, V_{Bt}]^T$	Vector
0	0	1	$2/3 V_{dc}$	$-1/3 V_{dc}$	$-1/3 V_{dc}$	$2/3 V_{dc} \angle 0^\circ$	\vec{V}_1	V_{dc}	0	$-V_{dc}$	$2\sqrt{3} V_{dc} \angle -30^\circ$	\vec{V}_1
1	0	1	$1/3 V_{dc}$	$-2/3 V_{dc}$	$1/3 V_{dc}$	$2/3 V_{dc} \angle 60^\circ$	\vec{V}_2	V_{dc}	$-V_{dc}$	0	$2\sqrt{3} V_{dc} \angle 30^\circ$	\vec{V}_2
1	0	0	$-1/3 V_{dc}$	$-1/3 V_{dc}$	$2/3 V_{dc}$	$2/3 V_{dc} \angle 120^\circ$	\vec{V}_3	0	$-V_{dc}$	V_{dc}	$2\sqrt{3} V_{dc} \angle 90^\circ$	\vec{V}_3
1	1	0	$-2/3 V_{dc}$	$1/3 V_{dc}$	$1/3 V_{dc}$	$2/3 V_{dc} \angle 180^\circ$	\vec{V}_4	$-V_{dc}$	0	V_{dc}	$2\sqrt{3} V_{dc} \angle 150^\circ$	\vec{V}_4
0	1	0	$-1/3 V_{dc}$	$2/3 V_{dc}$	$-1/3 V_{dc}$	$2/3 V_{dc} \angle 240^\circ$	\vec{V}_5	$-V_{dc}$	V_{dc}	0	$2\sqrt{3} V_{dc} \angle 210^\circ$	\vec{V}_5
0	1	1	$1/3 V_{dc}$	$1/3 V_{dc}$	$-2/3 V_{dc}$	$2/3 V_{dc} \angle 300^\circ$	\vec{V}_6	0	V_{dc}	$-V_{dc}$	$2\sqrt{3} V_{dc} \angle 270^\circ$	\vec{V}_6
0	0	0	0	0	0	0	\vec{V}_7	0	0	0	0	\vec{V}_7
1	1	1	0	0	0	0	\vec{V}_8	0	0	0	0	\vec{V}_8

Possible Switch Combinations (note: 0 = Switch OFF, 1 = Switch ON), Equivalent Line to Neutral Voltage Vectors and Equivalent Line to Line Voltage Vectors.

Fig. 20



Line to Neutral Voltage Vectors Projected Onto The DQs Axis (Note: (001) = S_{Ct} OFF, S_{Bt} OFF, S_{At} ON)

Line to Line Voltage Vectors Projected Onto The DQs Axis (Note: (001) = S_{Ct} OFF, S_{Bt} OFF, S_{At} ON)

Fig. 21




Fig. 22




Fig. 22a




Fig. 23

Equivalent Watt - Seconds as Computed from Overload Characteristics Curve




Fig. 24




Fig. 25




Fig. 26




Fig. 27




Fig. 28




Fig. 29




Fig. 30




Fig. 31




Fig. 32 Discrete time servo compensator




Fig. 33 Discrete time servo compensator (cont.)




Fig. 35




Fig. 36





Fig. 37



38